

DXI Technical Manual

Table of Contents

Section	General	<u>Document No.</u>
Section 1	General	
	DXI/DXL Brochure	DXI/DXL Brochure
	DXI 400 Series System Data Sheet	DS-DXI-400-2.3
	DXI 400 Series System Description	DS-DXI-450-2.4
Section 2	Planning	
	System Planning Guide	MN-DXI-SPG-APR02
	System Planning MicroComm DXI/DXL Cable Specifications	MN-DXI/DXL-MCS-FEB10
Section 3	Operation	
	Intercom Master Station Operating Instructions	MN-IMS-F1-NOV03
	Telephone Set Master Station Operating Manual	MN-TSM-F1-FEB02
	Quick Guide Master Station Operation	MN-IMS-Q1-APR05
Section 4	Administration	
	System Administration Manual	IM-SAC-ADM-APR03
Section 5	Maintenance	
	Maintenance Manual	IM-SAC-MNT-FEB02
Section 6	Troubleshooting	
	Troubleshooting Guide	IM-DXI-TBL-NOV02
	MicroComm DXI Hardware – Quick Reference	IM-DXI-REF-MAR09
	DXI Quick Troubleshooting Guide	IM-DXI-QTG-SEP09
Section 7	Host Port Communications	
	DXI Host Port Command/Status Messages	IM-MES-DXI-R14.5
	DXI TCP/IP Host Protocol	IM-PROT-MODTCP-R2.2
	DXI Omron Host Protocol	IM-PROT-OMRON-R1.1
	DXI Host Communications Protocol (Serial)	IM-PROT-SERIAL-R2.1
	DXI Host Communications Protocol (TCP/IP)	IM-PROT-TCP-IP-R1.2
Section 8	DXI Installation Bulletins	
	ACB-101 Audio Control Board	IM-ACB-101-1.4

AIB-100/400 Audio Input Board	IM-AIB-100/400-2.6
AIO-100/400 Audio Input/Output Board	IM-AIO-100/400-2.6
AOB-100/400 Audio Output Board	IM-AOB-100/400-2.6
ATB-101 Audio Trunk Board	IM-ATB-101-1.1
CRI-100 Card Reader Interface	IM-CRI-100-1.1
CRI-200 Rack Mount Dual Card Reader Interface	IM CRI-200-1.1
FTR-120 Free Topology Repeater	IM-FTR-120-3.0
IOC-110 I/O Card Cages	IM-IOC-110-2.1
PAB-100/400 Paging Amplifier Board	IM-PAB-100/400-2.4
PAB-401 Paging Amplifier Board	IM-PAB-401-2.1
PSU-310 Power Supply	IM-PSU-310-2.4
PSU-530 N+1 Redundant Power Supply	IM-PSU-530-1.1
Remote Drivers and Receivers	IM-RIO-100-2.4
RNS-100 Redundant Network Switch	IM-RNS-100-1.2
SAB-300 Station Audio Board	IM-SAB-300-2.5
SAB-400 and SAB-401 Station Audio Board	IM-SAB-400/401-2.5
TLB-400 Telephone Line Board	IM-TLB-400-1
TSB-100 and TSB-400 Telephone Set Board	IM-TSB-100/400-2.5

Section 9 MicroComm Installation Bulletins

ACP-130 Annunciator Control Panel	IM-ACP-130-1.2
ACP-135 Annunciator Control Panel	IM-ACP-135-1.2
COD-210 Call Operating Device	IM-COD-210-1.1
100 and 300 Series DIO Modules	IM-DIO-100-2.7
DSM-140 Desktop Speaker Microphone	IM-DSM-140-1.1
FDH-420/440 Full Duplex Handset	IM-FDH-420/440-1.6
FST-420 Fiber Station Transceiver	IM-FST-420-1.0
HHK-132 Magnetic Hookswitch/Handset Kit	IM-HHK-132-1.1
HHK-133 Magnetic Hookswitch/Handset Kit	IM-HHK-133-1.1
ICE-400 Series Intercom Stations	IM-ICE-400-1.0
400 Series Intercom Stations	IM-ICM-400-2.13
400 Series Intercom Station Repair Kit	IM-ICM-400-Repair Kit
IMS-130 Intercom Master Station	IM-IMS-130/MAI-420-2.9
IMS-440 and IMS-445 Intercom Master Stations	IM-IMS-440-2.6
MAI-425 Master Audio Interface	IM-MAI-425-2.8
QCB-120-6 Quick Connect Board	IM-QCB-120-6-Pv1
Speaker/Microphone Kit	IM-SMK-1-1.2
TMM-440 Touchscreen Master Module	IM-TMM-440-1.1
TMM-441 Touchscreen Master Module	IM-TMM-441-1.0
VBS-420 Visitor Booth Station	IM-VBS-420-2.8

Section 10 Application Notes

DXI SAC Software: Configuring a CCTV Switcher	DXI-APP-100-1.0
TCP/IP Host Protocol Example Design	DXI-APP-101-1.0
DXI SAC Software: External Protocol Support	DXI-APP-102-1.1
DXI SAC Software: Paging using external amplifiers and DIO relay outputs	DXI-APP-103-1.0
Installing Kermit and/or FTP support for a DXI Admin Computer	DXI-APP-104-Pv3
DXI SAC Software: Common command line commands for the DXI system	DXI-APP-105-1.0
Connecting and Using a Headset with a MicroComm DXI Intercom Master Station	DXI-APP-106-P
DXI SAC Software: Audio Level Alarm Settings	DXI-APP-107-P
Creating a Station Acknowledge Tone for a DXI System	DXI-APP-108-1.0
DXI Configuration Example	DXI-APP-109-Pv1.1